



Flush mount frame option

Note: The door is 1/2" lower than the frame. This allows you to cut a 1/2" piece of plywood to cover the door and the gap between the door and frame. Making it flush with the slab. Drill two "finger holes" to make it easy to remove.